
















Read the instructions carefully before assembling and using the product.
Assembling process can be completed by non-professionals.
For indoor use only. This product does not require maintenance.










CC-B110, CM-36





Pleated, single







i There are multiple positions available for the support hook.







i It is possible to remove runners.



! Make sure the motor is locked correctly.

